


QUICK GUIDE

Cable Harness



① **Cable harness connector to Control Box:**

② **Main Switch:**

(0) - OFF (1) - ONLY DETECTION & PARKING SENSOR (2) - JAMMER

③ **LED feedback:**

STATIC GREEN: ready to JAM

BLINKING GREEN: in parking sensor mode

RED/GREEN: jamming in process (also the buzzer is beeping)

④ **Buzzer:**

Gives beeping alerts from jamming and parking sensor mode.

⑤ **Safety KILL BUTTON:**

Pushing more than 5s the Control Box kill the jammer function and only can reset it by our engineers. After KILL the Control Box, it's working only in Parking sensor. Simple you don't have jammer anymore.

⑥ **BLACK wire:**

Negative power supply - Ground

⑦ **RED wire:**

Constant +12V power supply! This is for the KILL BUTTON to make it work even if there is no ACC or ignition on the car.

⑧ **YELLOW wire:**


Connect to ACC +12V. This is the main power supply for the product.



Attention!

Do not push and hold the red safety button. For further information about that, please make contact with your seller.

JAMMING TIME ADJUSTING POTMETER



- \emptyset value
Only detection no JAM
- ∞ value
Constant Jamming
- 1-7 value
**Jamming time in seconds
Restart 1 minute.**

